




Dell Vostro 1320 Fan Replacement

Replace your computer fan if it is no longer working.

Written By: Christie Lloyd






TOOLS:




- [64 Bit Driver Kit](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Fan




- Turn the laptop over so that the bottom of it is exposed.
- The section of the computer that we need to access is the right panel. You need to start by using the J00 bit attachment to the Bit Driver to unscrew the screw

Step 2





- Use the flat Metal Spudger to open the plastic panel.
- If the panel does not open right away try placing the flat Metal Spudger to the adjacent or opposite side of the plastic panel.

Step 3




- Unplug the wire connecting the fan to the computer

Step 4



- Remove the four screws by using the Bit driver.

Step 5



- Gently pull the fan away from the side of the computer. Lift it out completely.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-11 02:07:49 AM.